[Issue Descriptions]: (RG100) LED Light Blinks: Alarm

1. Check the SIM Card expiration date, data plan, or installation.

2. Check if the local 4G/LTE signal is not strong.

3. Check if the account, password, and web configuration are correct.