

[Issue Descriptions]: The screen is shaking or waving.

- Press ◀ (the Auto - adjustment control) to adjust.
Moving all objects which emit a magnetic field such as motor or transformer, away from the monitor.
- Check if the specific voltage is applied.
- Check if the signal timing of the computer system is within the specification of monitor