

[Issue Descriptions]: Clear abnormal information after replacing the RTC battery

1. With the battery/adapter plugged in, press the reset button
2. Press for about 2-3 seconds
3. Unplug the battery/adapter and plug it in again