

[Issue Descriptions]: How to adjust auto power-on on IE32 mainboard

1. Go to the BIOS menu
2. Choose Advance sub-menu
3. Select SIO F81968
4. Go to option "Restore On Power Loss"
5. Set to "Always On"

