

[Issue Descriptions]: How To Disable Turbo Mode

1. Go to the BIOS menu by click "DEL" several times during boot time.
2. Choose "Advance" menu.
3. Click "Turbo mode" and choose disable.

