

[Issue Descriptions]: (RG100) Radio Audio Malfunction

1. If the audio keeps on and off, please check if the local 4G/LTE signal is not good.
2. If audio is mixed with noises and goes on for a while, unplug the power, replug, and power up.
3. If the signals are transmitted well between radios and smartphones App, but there is no audio output, please unplug the power, replug and power up again.