

[Issue Descriptions]: Barcode_Barcode scanner has no laser and does not work

- Make sure the Barcode scanner device is enabled in Hottab utility.
- Make sure under Windows, the Barcode Reader is set to COM 15 port, so that Hottab can trigger the Barcode Reader hardware.