

[Issue Descriptions]: The removable battery is not charging

- Make sure the AC adapter is properly connected, and that the removable battery is properly inserted.