

[Issue Descriptions]: RFID scanner does not work

- Make sure under Windows, the RFID hardware is set to COM 3 port.