

[Issue Descriptions]: Nothing appears on the screen

1. The laptop may be in sleep mode. Press the power button to wake up the display.
2. The brightness level may be too low. Increase brightness.
3. The display device might be set to an external monitor. Press the display toggle hotkey to toggle the display back to the computer.