

[Issue Descriptions]: No sound is produced

- Adjust volume of the tablet computer by pressing on the volume rocker.
- If using an external audio device, make sure that the cable is properly connected.